

DY18

AUTOMOTIVE ELECTRIC SYSTEM TESTER

- Quickly check if a circuit is Positive, Negative or Open by probing it and observing the RED or GREEN LED
- Quickly activate and check electric components by pressing power switch to (-) or (=) position to determine their electronic and grounding status
- Test continuity of switches, relays, diodes, fuses and wires by connecting them between the auxiliary ground lead and the probe tip and observing the GREEN LED
- Find faulty ground connections instantly
- Follow and locate short circuit

NEW
2019



SPECIFICATION **DY18**

Operation Voltage	6-24V DC
Overload Protection	10A
Lead Length	approximately 4M (13F)

